

Adresse	Dipswitch Einstellung
241	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
242	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
243	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
244	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
245	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
246	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
247	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
248	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
249	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8
250	ON □ □ □ □ □ □ □ □ 1 2 3 4 5 6 7 8



ADRESSIERUNGSTABELLE

Vielen Dank für Ihr Vertrauen in unsere Produkte
Olympia Electronics – Europäischer Hersteller

Adresse	Dipswitch Einstellung	Adresse	Dipswitch Einstellung	Adresse	Dipswitch Einstellung	Adresse	Dipswitch Einstellung
1		31		61		91	
2		32		62		92	
3		33		63		93	
4		34		64		94	
5		35		65		95	
6		36		66		96	
7		37		67		97	
8		38		68		98	
9		39		69		99	
10		40		70		100	
11		41		71		101	
12		42		72		102	
13		43		73		103	
14		44		74		104	
15		45		75		105	
16		46		76		106	
17		47		77		107	
18		48		78		108	
19		49		79		109	
20		50		80		110	
21		51		81		111	
22		52		82		112	
23		53		83		113	
24		54		84		114	
25		55		85		115	
26		56		86		116	
27		57		87		117	
28		58		88		118	
29		59		89		119	
30		60		90		120	

Adresse	Dipswitch Einstellung	Adresse	Dipswitch Einstellung	Adresse	Dipswitch Einstellung	Adresse	Dipswitch Einstellung
121		151		181		211	
122		152		182		212	
123		153		183		213	
124		154		184		214	
125		155		185		215	
126		156		186		216	
127		157		187		217	
128		158		188		218	
129		159		189		219	
130		160		190		220	
131		161		191		221	
132		162		192		222	
133		163		193		223	
134		164		194		224	
135		165		195		225	
136		166		196		226	
137		167		197		227	
138		168		198		228	
139		169		199		229	
140		170		200		230	
141		171		201		231	
142		172		202		232	
143		173		203		233	
144		174		204		234	
145		175		205		235	
146		176		206		236	
147		177		207		237	
148		178		208		238	
149		179		209		239	
150		180		210		240	